

<u>noyradon odenci</u>

Fig.2

DATA AREA NAMES	STORAGE PLACE	SIZE
PARAMETER 1 (RECORDING TIMING) BIT 0: RECORD WHEN THE POWER SUPPLY IS TURNED ON BIT 1: RECORD WHEN THE APPARATUS IS RESUMED BIT 2: RECORD WHEN BIOS SETUP PROGRAM IS ACTIVATED BIT 3: RECORD WHEN AN ILLEGAL PASSWORD IN ENTERED	CMOS RAM	1 BYTE
PARAMETER 2 (FORMAT) NUMBER OF PIXELS/NUMBER OF COLORS, etc.	CMOS RAM	1 BYTE
PARAMETER 3 (WRITING MODE) 0: OVERWRITING 1: APPENDING	CMOS RAM	1 BYTE
IMAGE DATA MANAGEMENT HEADER POINTER FOR LEADING IMAGE DATA	FLASH MEMORY	4 BYTES
IMAGE DATA POINTER FOR THE NEXT IMAGE DATA TIME WHEN IMAGE DATA IS RECORDED TIMING OF RECORDING IMAGE DATA IMAGE DATA FORMAT DATA	FLASH MEMORY	4 BYTES 8 BYTES 1 BYTE 1 BYTE n BYTES

Fig.3A

FUNCTION:	FUNCTION: RETURN THE CURRENT SETTING OF IMAGE INFORMATION RECORDING TIMING
WORD (*ent WORD Funct BYTE *Trig	WORD (*entryPoint)(Function,Trigger); WORD Function; WYTE *Trigger;
*Trigger: Bit[7:4] Bit[3] Bit[2] Bit[1] Bit[0]	RESERVE O: NO RECORDING HAPPENS WHEN AN ILLEGAL PASSWORD IS ENTERED 1: RECORDING HAPPENS WHEN AN ILLEGAL PASSWORD IS ENTERED O: NO RECORDING HAPPENS WHEN BIOS SETUP PROGRAM IS ACTIVATED 1: RECORDING HAPPENS WHEN THE APPARATUS IS RESUMED O: NO RECORDING HAPPENS WHEN THE APPARATUS IS RESUMED O: NO RECORDING HAPPENS WHEN THE POWER SUPPLY IS TURNED ON 1: RECORDING HAPPENS WHEN THE POWER SUPPLY IS TURNED ON
FUNCTION:	FUNCTION: SET IMAGE INFORMATION RECORDING TIMING
	DITTO

Fig.3B

FUNCTION: RETURN THE CURRENT SETTING OF IMAGE INFORMATION RECORDING FORMAT	
WORD (*entryPoint)(Function,Format); /*For 32bit Protected Mode*/WORD Function; /*Function 0x0002*/BYTE *Format;	* 0)
*Format: Bit[7:4] THE NUMBER OF PIXELS 0: 320x240	
1: 640x480 2: 1024x768 etc. Bit[3:0]	
1: 8bit(256) 2: 16bit(65536)etc.	
FUNCTION: SET IMAGE INFORMATION RECORDING FORMAT	
ጋተተር ገ	

4/10

Fig.3C

			5/10		
FUNCTION: RETURN THE CURRENT SETTING OF IMAGE INFORMATION WRITING MODE	WORD (*entryPoint)(Function, Mode); WORD Function; BYTE *Mode;	*Mode:	Bit[7:0] WRITING MODE 0: OVERWRITING 1: APPENDING	FUNCTION: SET IMAGE INFORMATION WRITING MODE	DITTO

Fig.4

IMAGE RECORDING	
IMAGE RECORDING STATUS:	EXIST
DISPLAY RECORDED IMAGE	(Enetery)
WHEN THE POWER SUPPLY IS TURNED ON: WHEN THE SYSTEM IS RESUMED: WHEN THE BIOS SETUP IS ACTIVATED: WHEN ILLEGAL PASSWORD IS ENTERED:	(NO RECORD) (NO RECORD) (NO RECORD) (RECORD)
IMAGE SIZE: IMAGE COLORS:	[640x480 PIXELS] [256 COLORS]
RECORDING MODE:	(APPENDING)
DELETE RECORDED IMAGE	(Eneter)

F i q. 5

2000/01/01 00:00:00 ILLEGAL PASSWORD ENTRY (IMAGE DATA DISPLAYED) (DISPLAY THE PREVIOUS DATA) (RETURN)				
IMAGE RECORDING 2000/01/01 00:00:00 ILLEGAL PASSWORD ENTRY (IMAGE DATA DISPLAYED) (DISPLAY THE PREVIOUS DATA) (DISPLAY THE NEXT DATA)				[RETURN]
2000/01/01 00:00:00 ILLEGAL PASSV (IMAGE (DISPLAY THE PREVIOUS DATA)	AGE RECORDING	JORD ENTRY	DATA DISPLAYED)	KDISPLAY THE NEXT DATA)
50	WI	00/01/01 00:00:00 ILLEGAL PASSW	(IMAGE	[DISPLAY THE PREVIOUS DATA]
		2		











